




ELOQUENCE®

Maison Fondée en 2002

GUSTAVIAN DINING TABLE


Assembly Instructions & Care



PARTS INCLUDED



Allen Key – Qty. 1



Allen Bolts – Qty. 8






Table Top – Qty. 1





Legs - Qty. 4



Washers – Qty.8

SAFETY INSTRUCTIONS

1. Always exercise care and precaution when moving heavy furniture, to avoid injury and/or damage to the product. You will need at least two people for this installation. Be mindful when moving and placing furniture as to not damage the piece of flooring.
2. Periodically check all fixtures to ensure none have come loose. Re-tighten when necessary. Incorrect assembly of furniture can be dangerous, so please follow our directions.
3. No liability will be accepted for any damage or injury caused by incorrectly assembled furniture.



ASSEMBLY INSTRUCTIONS

1. Provide a clean and clear area where you will be installing the table. The table top will need to be placed on the floor with top facing down. Each leg is numbered with a sticker to the corresponding corner. Begin with placing the first leg upside down into the corresponding corner of the table, the leg will fit snugly between the aprons.
2. Once the leg is in place, align the bolt holes and thread the washer onto the bolt and carefully use an Allen key to tighten the bolt into the aprons.
3. Repeat this step on all four legs while the table is upside down. Once all legs are securely bolted together, and with help, flip the table right side up.

CARE INSTRUCTIONS

The use of coasters or placemats helps to prevent marks or stains on wooden tabletop.

When cleaning, wipe the tabletop with a diluted solution of mild detergent and warm water.

Always clean the whole top rather than one area, to avoid any patches of discoloration over time.



ELOQUENCE®

Maison Fondée en 2002

WWW.ELOQUENCE.COM

3601 Holdrege Ave.

Los Angeles, CA 90016

T: 310-876-0661 F: 310-876-0667

E: INFO@ ELOQUENCE.COM